

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE



INSTALLATION

1 Install Rods

Optional Rods:

8 Feet Ceiling:
(2) 12"L Rods.

9 Feet Ceiling:
(2) 6"L Rods + (2) 12"L Rods.

2 Remove Swivels from Ceiling Canopy

3 Install Swivels, Ceiling Canopy and Lanyards to Upper Rods

Swivel

90Degree

For angled ceilings, Swivels opening towards wall.

* Make sure two swivels opening are in the same direction while assembling.

4 Install Inner Backplate

Outlet Box

1/4" Hole

5 Install Lanyards

Button Stop

Lanyard

6 Wiring

White wire from supply

Black (or red) wire from supply

Ground wire from supply


White from driver

Black from driver


Ground wire from fixture

Green ground screw

7 Install Ceiling Canopy to Inner Backplate



8 Install Bulbs



Your installation is now complete! Restore electricity and save this sheet for future reference.